Zeitler AG



Cable feeding tool **EZ.BOOSTER**

For fiber optic cables





the easy and smooth way to insert fiber optic cables in micro-ducts.

Facts

- Tool for pressed air-aided insertion of fiber optic cables (diameter 0.5 mm - 8.0 mm)
- Quick and safely
- Easy to handle
- To be used with a standard compressor
- Feeding up to 500 m of fiber optic cable
- · Lightweight and compact
- Complete set for cable dimensions:
 - * 0,5-1.0 mm
 - * 1.0-2.0 mm
 - * 2.0-3.0 mm
 - * 3.0-4.0 mm
 - * 4.0-5.0 mm
 - * 5.0-6.0 mm
 - * 6.0-7.0 mm
 - * 7.0-8.0 mm



Standard kit in transport box

- √ 1 EZ.BOOSTER basic tool
- √ 1 entrance plate (green) according to selected cable dimension
- 1 connection plate (violet) according to selected cable dimension (to connect EZ.SPEEDY)
- √ 5 tube couplings (6,8,10,12 und 14 mm)
- √ 1 tube reductor 8/7mmm
- ✓ 1 Torx wrench T20
- √ 1 small container with 20 rubber disks according to selected cable dimension
- √ 1 small container with 6 spare screws
- √ 1 operating manual



Zeitler AG



Cable feeding tool **EZ.BOOSTER**

For fiber optic cables

Scope

Tool for pressed air-aided insertion of fiber optic cables (diameter 0.5 mm to 8.0 mm) in micro-ducts. With the EZ.BOOSTER connected to a standard compressor you have a simple and easy way to feed fiber optic cables quickly and safely into micro-ducts. Insertion length up to 500 m. In combination with the EZ.SPEEDY performance can even be improved.

Application

EZ.BOOSTER

- Select and assemble rubber discs according to cable dimension
- Select and assemble entrance plate (green) according to cable dimension
- Screw on tube coupling
- Connect micro-duct to EZ.BOOSTER
- Insert fiber optic cable into EZ.BOOSTER (approx. 1 m)
- Connect pressed air hose to EZ.BOOSTER and switch on compressor
- Push fiber optic cable step by step and smoothly into micro-duct.



FZ BOOSTER Video

EZ.BOOSTER in combination with EZ.SPEEDY

- Select and assemble rubber discs according to cable dimension
- Select and assemble connection plate (violet) according to cable dimension
- Screw on tube coupling
- Connect micro-duct to EZ.BOOSTER
- Screw on coupling front to EZ.SPEEDY
- Connect EZ.SPEEDY to EZ.BOOSTER
- Fit hex bit holder to cordless drill
- Controle/select speed torque
- Insert fiber optic cable through cable guides (insert approx. 1 m) into micro-duct
- Close EZ.SPEEDY handles
- Connect pressed air hose to EZ.BOOSTER and switch on compressor
- Fit cordless drill to one of the hex screws and start operating the drill
- Fiber optic cable will be inserted quickly, smoothly and evenly into micro-duct.

